

INSTRUCTIONS D'UTILISATION

Lisez attentivement ces instructions avant d'utiliser l'assiette et conservez-les pour pouvoir vous y référer ultérieurement.

Age d'utilisation : 12 mois à 6 ans.

Utilisation du produit

- Peut être utilisé au four à micro-ondes pour réchauffer les aliments.
- Ne pas utiliser au four traditionnel
- Température maximale tolérée : 65°C
- Avant la première utilisation, nettoyer l'assiette.
- Vérifier l'assiette avant chaque utilisation. Si vous remarquez quelque dégradation que ce soit, arrêter d'utiliser cette assiette immédiatement.

Nettoyage:

- Nettoyer au lave-vaisselle.

Rangement :

- Ranger l'assiette à l'abri de sources de chaleur ou de la lumière directe du soleil.

Pour la sécurité de l'enfant et par mesure d'hygiène : AVERTISSEMENT !

- Ce produit doit toujours être utilisé sous la surveillance d'un adulte.
- Avant chaque utilisation, examiner le produit. Le jeter dès les premiers signes de détérioration ou fragilité.
- Toujours vérifier la température de l'aliment avant de donner à manger à l'enfant.
- Le chauffage au four micro-ondes peut engendrer localement de hautes températures.
- Redoubler de prudence en cas de chauffage au four à micro-ondes.
- Toujours remuer l'aliment une fois chauffé pour garantir une répartition uniforme de la chaleur.

Norme en vigueur: EN 14372

INSTRUCTIONS

Read these instructions carefully before using the plate and keep them for future reference.

Age of use: 12 months to 6 years.

Used of the product:

- Can be used in the microwave to heat food.
- Do not use in the oven
- Maximum temperature tolerated: 65°C (149F).
- Before first use, clean the plate.
- Please check the plate before each use. If you notice any degradation, stop using this plate immediately.

Cleaning:

- Clean in the dishwasher.

Storage:

- Keep the plate away from sources of heat or direct sunlight.

For your child's safety and health measure:

WARNING !

- Always use this product with adult supervision.
- Before each use, inspect the product. Throw away at the first sign of damage or weakness.
- Always check the temperature of the food before feeding the child.
- Heating in a microwave oven may produce localised high temperatures.
- Take extra care when microwave heating.
- Always stir food to ensure even heat distribution and test the temperature before serving.

Valid norm: EN 14372